

RDM tool for EUCO-2K1200GDA

User Manual V0.0. 0

Revision history

Revision	Changes	Author	Date
V0.0. 0	Official release	David.Zhou	2023/03/31

Contents

1. Connect the device.....	4
2. Open DMX512&RDM programming software.....	4
3. Programming the output current	5
4. Set LED OTP parameters	8
5. Set address mode.....	8
6. Set DMX512 address	10
7. Set default level	10
8. Save& Load profile	11
9. Firmware update.....	12
10. Add-on functions.....	16

1) Connect the device

Before launching the DMX512&RDM programming software, make sure the programmer is connected to the USB port of your computer. Then, connect the programmer SDPTDV05UAB to the LED driver via RDM+ /RDM- terminal (The RDM interface is polarity sensitive). After all of this, the target driver must be AC mains powered on during the whole process of operation. The connection is described in the following figure. It is recommended to connect to LED fixture during the programming. The driver will turn the light on and off to indicate the current programming is carried in correct order. For simplicity, the programming could be carried out without LED fixture connection.




Figure 1. The connection of the DMX512&RDM programming tool




Figure 2. The picture of the DMX512&RDM programming tool

Note that when the tool is connected to the computer for the very first time, it may take a few minutes to install a driver automatically. Please wait patiently for the installation to finish.

2) Open DMX512&RDM programming software

Double click “**RDM_Tool_For_EUCO-2K1200GDA_S00E01.exe**” to start the software.




Figure 3 Open DALI programming software

3) Program the output current

Before programming the output current, please make sure the driver has properly connected and worked fine. Then turn on the AC power.

Step 1: The GUI interface of DMX512&RDM programming tool is shown in the following figure. Firstly, after opening the software, make sure the status light becomes green which means that the DMX512&RDM programming tool has connected successfully. Otherwise, follow step “I-Connect the device” to check the USB cable and DMX512&RDM bus.




Figure 4 the software of DMX512/RDM programming tool

Step 2: There are four items of current channel you can choose as shown below:




Figure 5. Choose current channel

If you select the item “**All**”, it means that you would program the current of all three channels at once. And the channel, “CH01”, “CH02” and “CH03”, would only program the corresponding channel’s current.

Step 3: After choosing the programming channel, the current value of that channel also need to be set. The default value for each channel is 2000mA as show in the figure. The current value range can be set from 700mA to 2000mA.




Figure 6. Set current value

Step 4: If the programming parameters have been set completely, click “**Write**” button. Then the driver would light-off and light-on automatically. And the status message at the bottom will show

“Current programming successfully”.

Note: The” Current programming successfully” only means that the commands have be sent out. To check the programming is successful or not, please click the “Read” button to verify the programed current value.

The screenshot shows the 'DMX512&RDM Program Tool' interface. At the top, there are 'Save' and 'Load' buttons. Below them is the title bar. The main area contains several sections: 'Operating mode' with a 'Mode' dropdown set to 'Single address' and a 'CH01' dropdown, with 'Write' and 'Read' buttons; 'DMX512 default level' with a 'Level' dropdown set to '255' and 'Write' and 'Read' buttons; 'Device address' with an 'Address' dropdown set to '1' and 'Write' and 'Read' buttons; 'Current programming' with a 'Channel' dropdown set to 'All', a 'Current' input field set to '2000' mA, and 'Write' and 'Read' buttons; 'OTP on LED fixture' with a 'Trigger point' input field set to '100' °C and 'Write' and 'Read' buttons; and 'Dimming' with a 'Level' slider set to '0' and a 'Dimming' button. At the bottom, a green circle icon is next to the text 'Current program successfully', which is highlighted by a red rectangular box.

Figure 7. Current program successfully

Step 5: After current programming, click “**Read**” button to check if the programming value is right.

This screenshot shows the same 'DMX512&RDM Program Tool' interface as Figure 7. The 'Current programming' section is highlighted with a red rectangular box around the 'Read' button. The 'Current' input field is set to '2000' mA. The 'Dimming' section shows a 'Level' slider set to '0' and a 'Dimming' button. At the bottom, a green circle icon is next to the text 'Current program successfully'.

Figure 8. Read current programming

4) Set LED OTP parameters

The driver has integrated the OTP function for the LED fixture via “NTC” terminal with a certain NTC component in LED fixture. Please refer to datasheet for the circuit details. For the OTP, there is one parameter need to be set: the NTC trigger point.

The screenshot shows the 'DMX512&RDM Program Tool' interface. At the top, there are 'Save' and 'Load' buttons. Below the title bar, the 'Operating mode' section has a 'Mode' dropdown set to 'Single address' and a 'CH01' dropdown, with 'Write' and 'Read' buttons. The 'DMX512 default level' section has a 'Level' input set to '255' with 'Write' and 'Read' buttons. The 'Device address' section has an 'Address' input set to '1' with 'Write' and 'Read' buttons. The 'Current programming' section has a 'Channel' dropdown set to 'All' and a 'Current' input set to '2000' mA, with 'Write' and 'Read' buttons. The 'OTP on LED fixture' section has a 'Trigger point' input set to '100' °C, which is highlighted with a red rectangle, and 'Write' and 'Read' buttons. At the bottom, the 'Dimming' section has a 'Level' slider set to '0' and a 'Dimming' button. A green status indicator at the bottom left shows a green dot and the text 'Current program successfully'.

Figure 9. Set OTP parameters

When the temperature of NTC component has exceeded NTC trigger point, it would start OTP protection process. Please refer to the driver's datasheet for full details of OTP.

In order to make sure the OTP protection works normal, some constraints have been introduced.

1. The range of NTC trigger point is 80°C~120°C. The default value is 100°C.

Also, click the “**Read**” button could read the current OTP setting.

Note: The message after writing only means that the commands have be sent out. To check the programming is successful or not, please click the “**Read**” button to verify the written value.

5) Set address mode

The EUCO-2K1200GDA RDM/DMX series have two different channel mode: Single address mode and Multiple address mode. The single address means that three current output channels share one DMX address. So the dimming actions of the three output channels are performed

uniformly. And multiple address mode means that the three output channel could be set as different addresses. When in this mode, the three output channel could be controlled independently. The default address mode is single address mode.




Figure 10. Address modes

After the address was written, the driver should power off and wait at least 30s, then power on again to make sure the new address mode works normal. Of course, click "**Read**" button could read current address mode.

6) Set DMX512 address

It should be noted that before setting DMX512 address, the address mode should be set first. When the driver is set as single address mode, there is only one address needed to be set. Otherwise, three addressed needed be set.

In the DMX512 or RDM network, every driver has its unique address. This address of driver could be set with the programming tool. The range of address is 1~512.

The screenshot shows the 'DMX512&RDM Program Tool' interface. At the top, there are 'Save' and 'Load' buttons. The title bar reads 'DMX512&RDM Program Tool' with a 'DELTA' logo. The interface is divided into several sections:

- Operating mode:** Mode is set to 'Single address' and 'CH01'. There are 'Write' and 'Read' buttons.
- DMX512 default level:** Level is set to 255. There are 'Write' and 'Read' buttons.
- Device address:** This section is highlighted with a red box. It shows 'Address' set to 1. There are 'Write' and 'Read' buttons.
- Current programming:** Channel is set to 'All' and Current is set to 2000 mA. There are 'Write' and 'Read' buttons.
- OTP on LED fixture:** Trigger point is set to 100 °C. There are 'Write' and 'Read' buttons.
- Dimming:** Level is set to 0. There is a 'Dimming' button.

At the bottom, a green status bar indicates 'Current program successfully'.

Figure 11. Set address

Click “**Read**” button would read current DMX512 address.

7) Set default level

It should be noted that before setting DMX512 address, the address mode should be set first. If the multiple address mode is chosen, the default level of every channel should be set.

In the DMX512&RDM network, the dimming command of DMX512 should be sent at least once a second. If the driver could not receive dimming command in two seconds, it will return to the default level.

You could click “Write” button to set this default level. Or click “Read” button to check current default level.

Save Load

DMX512&RDM Program Tool

Operating mode
 Mode: Single address CH01 Write Read

DMX512 default level
 Level: 255 Write Read

Device address
 Address: 1 Write Read

Current programming
 Channel: All
 Current: 2000 mA Write Read

OTP on LED fixture
 Trigger point: 100 °C Write Read

Dimming
 Level: 0 Dimming

● Current program successfully

Figure 12. Set default level

8) Save& load profile

Step1: Please click the “Save” button in the tool bar. The GUI would save current configured parameters.

Save Load

DMX512&RDM Program Tool

Operating mode
 Mode: Single address CH01 Write Read

DMX512 default level
 Level: 255 Write Read

Device address
 Address: 1 Write Read

Current programming
 Channel: All
 Current: 2000 mA Write Read

OTP on LED fixture
 Trigger point: 100 °C Write Read

Dimming
 Level: 0 Dimming

● Current program successfully

Figure 13. Save profile

The program will create a new folder in current path named “profile”. In this folder, the file with parameters is named “config.ini”.

Step2: Please click “Load” button to load the last saved profile.




Figure 14. Save profile


And every time the GUI starts, it will load the profile automatically.

9) Firmware update

In case that the software needs to be updated to the latest version, the “firmware update” function is available. Please make sure to only activate this function with formal notice from Delta.

Step1: Before updating the firmware, please make sure that the programming tool you are using is the latest version which the model number is SDPT05UAB. And, the AC power of the driver has been turned off for at least 30 seconds.

Step2: Click “**Firmware update**” button in the lower right corner. The firmware update interface would pop out.




The image shows the 'DMX512&RDM Program Tool' interface. At the top, there are 'Save' and 'Load' buttons. The title bar says 'DMX512&RDM Program Tool' with a DELTA logo. The interface is divided into several sections:

- Operating mode:** Includes a 'Mode' dropdown set to 'Single address', a 'CH01' dropdown, and 'Write' and 'Read' buttons.
- DMX512 default level:** Includes a 'Level' spinner set to '255', 'Write', and 'Read' buttons.
- Device address:** Includes an 'Address' spinner set to '1', 'Write', and 'Read' buttons.
- Current programming:** Includes a 'Channel' dropdown set to 'All', a 'Current' spinner set to '2000' mA, and 'Write' and 'Read' buttons.
- OTP on LED fixture:** Includes a 'Trigger point' spinner set to '100' °C, and 'Write' and 'Read' buttons.
- Dimming:** Includes a 'Level' slider and a 'Dimming' button.

At the bottom, there is a green status indicator labeled 'Connected' and a 'Firmware update' button.

Figure 15. Click Firmware update button



The image shows the 'Firmware update' dialog box. It has a title bar with a question mark and a close button. The interface includes:

- A file selection field with a 'Browse' button.
- Input fields for 'Size' and 'Checksum'.
- 'Firmware update' and 'Exit update mode' buttons.
- A progress bar showing '0%'.
- The DELTA logo at the bottom left.

Figure 15. the interface of firmware update

Step3: Click “**Browse**” button and choose the hex file that you are ready for updating. Please check the size and checksum of hex file in case of updating wrong file.




Figure 16. Choose hex file




Figure 17. Checksum and file size

Step 4: Click “**Firmware update**” button before power AC on. When a message “**Wait for AC power on ...**” pops up, turn on the AC power of driver. After the AC power is stable, click “**OK**” button.




Figure 17. Wait the Power AC on

If the MCU has already been in update mode, a message “MCU is ready for updating”

would pop out.




Figure 18. Message: MCU is ready for updating

Click “OK” button, the firmware update process would begin.




Figure 18. Update hex file

When the update is completed, “**Update successfully**” would pop out. The whole update process will take about one minute.




Figure 19. Update successfully

Step 5: Click button **“Exit Update Mode”** to exit update mode.




Figure 20. Exit update mode

10) Add-on functions

Note: Not all drivers supports this function. If you want use the add-on functions, please update the firmware to the latest version.

Step 1: Turn on the AC power, when the driver works normal, then open the GUI. If the driver supports the add-on functions, the GUI would be shown as below:




Figure 21. GUI with add-on functions

Step 2: Click the “ Add-on Functions”. There would pop out one new GUI.




Figure 22. GUI for add-on functions

There are two items in add-on functions: Constant lumen output, smart timer dim.

Constant lumen output: Luminance of most LED drivers would be attenuated more or less, with the same output current. So the driver supports this illumination compensation function to make sure to get the constant lumen.




Figure 23. GUI for CLO

There are 8 time steps and percent steps for the setting. The unit for time step is kHours. Please refer the datasheet of LED to get the curve between time and illumination. And the first time always

would be 0.

After key in all parameters, click on the “*Write*” button to start the writing process. Then the “*Read*” button could be clicked to check if the setting is correctly.

If the setting is successful, click “*Enable*” to start the CLO function. In avoid of flicker, the CLO ration only be updated when received the dimming command.

Smart timer dim: In this function, you could customize a dynamic dimming schedule in different modes




Figure 26. Different modes for STD

There are three modes to create an autonomous dimming schedule:

Fixed timer: It is a memoryless-based dimming mode that tracks the output level based on the programmed timing curve. The output level is organized by scheduled profile in the five steps.

Midnight centric timer: This mode is a memory-based that automatically measures over the past two days. The power on time of these two days is naturally corresponded to the night time. The midnight centric timer software calculates the length of power on time and centralized from the given virtual midnight point and changed the output level accordingly. More specifically, when the LED driver is power-on during the very first two days or the power-on time difference of past two days is more than 15minutes, the output current will fix to the maximum level since there is no valid data for reference. When the power-on time difference of past two days is less than 15minutes, the output level is controlled based on the correlation between the midnight point of programmed profile and yesterday power-on duration.

Ratio rescale timer: This mode is similar to midnight centric timer that records the power-on time based on the local night time. The ratio rescale timer software rescale programmed output power profile of each step by a calculated percentage of the recorded power-on time (when valid) out of given 5 steps duration.

Note: When all steps are finished, the light level remain in last level (level in step 5) for all three modes.

Fixed timer mode usage: The figure below shows the example of fixed timer dimming profile. In this case, the driver will perform 75% output level for the first two hours since power-up. Then change to 55% output level for following four hours (as step 2), follow by 35% output level for another three hours (as step3), and so on.




Figure 27. Fixed timer mode usage

Midnight centric timer mode usage: The figure below shows the midnight point is set to 23:00(dotted line) with typical five steps profile. If yesterday's time duration is six hours and valid, then the driver will perform the output level at 55% for one hour when power on, then follow by 35% for three hours, and so on.





Figure 27. Midnight centric timer mode usage

Ratio rescale timer mode usage: The figure below shows the same example of dimming profile as in fixed timer. If yesterday's time duration is six hours and valid. In this case, the ratio is going to be rescaled is 50% of original setting profile (total of twelve hours) for each step. Therefore, the driver will perform the output level at 75% for one hour (50% of setting profile) when power on. Then performs 55% output level for two hours, and so on.

For this function, it would be better to write the setting parameters. Click the "Write" button to configure the midnight shift and all schedule. Then click the "Write" button in the STD mode to choose one mode or disable all of them.

Constant lumen output **Smart timer dim****Smart timer dim curve****Mode**

Midnight centric timer

Write

Midnight Shift

0 mins

Parameters

Steps Percent/%

16:00

10

20:00

20

1:00

30

3:00

40

5:00

50

Read

Write