

Wiring method:

Fine-stranded

Connector: Wago 264 series

Use all three!

-Always use cable

DMX / RS-485

prevent reflections.

should be used.

used.

3.43 Nm

3.43 Nm

Vent to Chassi

0.6-0.8 Nm

-After 32 unit loads a

metres between the

M25 cable gland to Chassis

M20 cable gland to Cha

or 3105a

Solid

Stranded



