

1. Safety Instructions


- For enclosed and L frame type of power supply, to ensure sufficient convection cooling, always maintain a distance of ≥ 50 mm from all surfaces while the device is in operation.
- For open frame type of power supply, please ensure the mounted device is kept at ≥ 8 mm safety distance for D1 from other components and equipments (Refer to Fig. 3.1). Please insert an insulation sheet between the system and product, if the safety distance is < 8 mm for D2 (Refer to Fig. 3.2).
- · The device is not recommended to be placed on low thermal conductive surface, for example, plastics.
- Note that the enclosure of the device can become very hot depending on the ambient temperature and load of the power supply. Do not touch the device while it is in operation or immediately after power is turned OFF. Risk of burning!
- Do not touch the terminals while power is being supplied. Risk of electric shock.
- Prevent any foreign metal, particles or conductors to enter the device through the openings during installation. It can cause: Electric shock;
 Safety Hazard; Fire; Product failure
- · Battery need to be protected from short circuit while installation & servicing. Danger of explosion.
- · Signal connector should not interact with AC Input.
- Warning: The power supply must be mounted by metal screws onto a grounded metal surface. When connecting the device, secure Earth
 connection before connecting L and N. When disconnecting the device, remove L and N connections before removing the Earth connection.

For open frame type of installation, ensure the power supply's Protective Earthing (marked ® in Fig. 3.1) is connected to the system's Protective Earthing (PE). It is also recommended that the input FG (Fig. 1, ①) be connected to the system's PE.

2. Device Descriptions

▶ PJU-60W (Refer to Fig. 1)

- 1 Input connector
- 2 Output connector
- 3 DC voltage adjustment potentiometer
- 4 DC OK control LED (Green)
- ⑤ Signal connector (for PJU-□V60W□B□□ only)




*Please note that all images are for illustrative purposes only, and do not necessarily represent the exact products.




3. Installation of the Device

▶ PJU-60WC□□□ / PJU-60WL□□□: Enclosed / L Frame (Refer to Fig. 2.1, 2.2)




- The power supply shall be mounted on a sturdy heat conducting surface with minimum of 2 mounting holes (Fig. 2.1, (A)) for base mounting or side mounting. Use M3 screws only. The screw penetration into the chassis must be 3.5-4 mm. For the other mounting holes without screw threads, please use suitable screw and nut.
- Recommended mounting tightening torque: 4~8 Kgf.cm.



- (A) Mounting holes for enclosed and L frame type of power supply.
- B This surface belongs to customer's end system or panel where the power supply is mounted.
- © Input connector

▶ PJU-60WB□□□: Open Frame (Refer to Fig. 3.1, Fig. 3.2)




- (A) Mounting holes for open frame type of power supply. (1)
- ® Mounting hole should be connected to the system's protective earthing (PE). (1)
- © This surface belongs to customer's end system or panel where the power supply is mounted.
- D Input connector

Note (1): 4 × Ø3.30 Mounting Holes; Ø6 Max Dimension of Screw Head and Stand-off. Recommended mounting torque for tightening: 4~8 Kgf.cm.



4. Connection

Connector Type	Specific	cations			PJU-13V60W	PJU-27V60W
Terminal Block Connector (2)	DECA	Input (CN1)	Stranded or	mm²	0.32-3.3	0.21-3.3
			Solid Wire Size	AWG	22-12	24-12
			Torque	Kgf.cm	8.0	8.0
				lb in	7.0	7.0
		Output (CN2) - without Pin No. 1, 6	Stranded or Solid Wire Size	mm²	0.32-1.3	0.21-1.3
				AWG	22-16	24-16
			Torque	Kgf.cm	2.3	2.3
				lb in	2.0	2.0
		Output & Signal (CN2)	Stranded or Solid Wire Size	mm²	0.32-1.3	0.21-1.3
				AWG	22-16	24-16
			Torque	Kgf.cm	2.3	2.3
			Torque	lb in	2.0	2.0
Harness Connector	JST	Input (CN1)	Header (Board M	ounting)	B3P5-VH(LF)(SN)	
			Mating Connector		VHR-5N	
			Terminal		SVH-21T-P1.1	
			AWG		22-18	
		Output (CN2) - without Pin No. 1, 6	Header (Board Mounting)		B4P-VH(LF)(SN)	
			Mating Connector		VHR-4N	
			Terminal		SVH-21T-P1.1	
			AWG		22-18	
		Output & Signal (CN2)	Header (Board Mounting)		B6P-VH(LF)(SN)	
			Mating Connector		VHR-6N	
			Terminal		SVH-21T-P1.1	
			AWG		22-18	
	Molex	Input (CN1)	Header (Board Mounting)		26-62-4051	
			Mating Connector		26-03-3051	
			Terminal		08-52-0113	
			AWG		20-18	
		Output (CN2) - without Pin No. 1, 6	Header (Board Mounting)		26-60-4040	
			Mating Connector		26-03-3041	
			Terminal		08-52-0113	
			AWG		20-18	
		Output & Signal (CN2)	Header (Board Mounting)		26-60-4060	
			Mating Connector		26-03-3061	
			Terminal		08-52-0113	
			AWG		20-18	



Note (2): Terminal Block Connector

To secure reliable and shock proof connections, the stripping length should be 4-5 mm (see Fig. 4, 1). Please ensure that the wires are fully inserted into the connecting terminals as shown in Fig. 4, 2. All wire strands must be fully inserted into the terminals with the screws securely fastened in order to ensure safety and maximum contact.




5. Battery Information*

	PJU-13V60W	PJU-27V60W
Battery Capacity	3.2AH - 15AH	3.2AH - 7.2AH


^{*}For more information, please refer to the product datasheet.

6. Installation of Mounting Accessories (Refer to Fig. 5)




- Only use M3 screw 3.5-4mm through the base or side mounting holes. This is to keep a safety distance between the screw and internal components.
- Recommended mounting tightening torque: 4~8 Kgf.cm.

7. Power Derating Curve







Manufacturer:

Delta Electronics (Thailand) PCL. 909 Pattana 1 Rd., Muang, Samutprakarn, 10280 Thailand

Authorized Representative:

Delta Greentech (Netherlands) B.V. Zandsteen 15, 2132 MZ Hoofddorp, The Netherlands